




Front View



Back View





Setting Clock

- 1. Rotate the timer to **Clock Mode** position
- 2. Press MODE once to enter setting 12/24 hour mode
- 3. Press UP/DOWN to select 12 or 24 hour format
- 4. Press SET to enter setting clock hour
- 5. Press UP/DOWN to adjust hour
- 6. Press SET to enter setting clock minute
- 7. Press UP/DOWN to adjust minute
- 8. Press **MODE** *twice* to finish setting the clock

If you do not press any button for **10** seconds,

clock setting mode will be canceled.

Setting <u>Alarm</u>

1. Rotate the timer to **Clock Mode** Dosition

2. Press **MODE** *twice* to enter setting *alarm* mode


3. Press **SET** to enter setting alarm *hour*

4. Press UP/DOWN to adjust hour

5. Press **SET** to enter setting alarm *minute*

6. Press UP/DOWN to adjust minute

7. Press MODE to finish setting the alarm



Using Timer

Start Countdown

Rotate the timer position to select a desired preset countdown time. The countdown starts automatically.

Pause/Resume Countdown

Press Pause button at the back of the timer to pause/resume countdown

Stop Countdown

Rotate the timer to **Clock Mode** position to stop countdown and go back to time clock mode

Auto Countup

After the countdown ends, the timer starts counting up automatically until it reaches 99:59 (Minute:Second)

Using Alarm Clock

How to cancel an alarm?

Rotate the timer to one of the preset timer positions, then rotate back to **Clock Mode** \bigcap_{Clock} position.

How to snooze an alarm?

Press **SNOOZE/LIGHT** will trigger snooze alarm for 4 minutes and the backlit of the clock LCD display will be on for 10 seconds.

Quick Tip:

If you need to delete an alarm quickly, try reinstalling

the batteries and resetting the time clock.

